

# Chapter 1

## Getting Started

Welcome to your new Kindle Touch. This short guide will familiarize you with all of the features and functionality of the Kindle Touch. Some features and functionality may not be available based on factors such as your country of residence or location.

### Registering your Kindle Touch


---

If you bought your Kindle Touch online using your Amazon account, it is already registered and ready to use. To verify, press the Home button and look for your Amazon user name in the upper left corner of the Home screen. If it says My Kindle or shows the name of a previous owner instead of your own Amazon account name, you'll need to register it. See [Setting up your Kindle](#) in this chapter for instructions on setting up and registering your device.

### Kindle Touch controls

---

You need to learn only a few simple controls to use your Kindle Touch.



**Home button:** This raised button takes you to the Home screen, where you'll find a list of books and other content stored on your Kindle.

**Headphone jack:** Plug in headphones to listen to an audiobook, background music, or content read aloud using Text-to-Speech.

**Charge indicator light:** This light is amber when your Kindle is charging and green when the battery is fully charged.